



Male Run Tee

KQ2Y/KQY

To branch the line from the female thread in the same direction and at 90°.

Applicable tubing O.D. mm	Connecting thread	Model	
		KQ2Y (White)	KQY (Black)
3.2	M5 X 0.8	KQ2Y23-M5	KQY23-M5
	R1/8	-01S	-01S
	R1/4	-02S	-02S
4	M5 X 0.8	KQ2Y04-M5	KQY04-M5
	M6 X 1	-M6	-M6
	R1/8	-01S	-01S
	R1/4	-02S	-02S
6	M5 X 0.8	KQ2Y06-M5	KQY06-M5
	M6 X 1	-M6	-M6
	R1/8	-01S	-01S
	R1/4	-02S	-02S
8	R1/8	KQ2Y08-01S	KQY08-01S
	R1/4	-02S	-02S
	R3/8	-03S	-03S
10	R1/8	KQ2Y10-01S	KQY10-01S
	R1/4	-02S	-02S
	R3/8	-03S	-03S
	R1/2	-04S	-04S
12	R1/4	KQ2Y12-02S	KQY12-02S
	R3/8	-03S	-03S
	R1/2	-04S	-04S
16	R3/8	KQ2Y16-03S	KQY16-03S
	R1/2	-04S	-04S

<M5, M6>

<R>

Union "Y"

KQ2U/KQU

To branch tubing in the same direction.

Applicable tubing O.D. mm	Connecting thread	Model	
		KQ2U (White)	KQU (Black)
3.2	M5 X 0.8	KQ2U23-M5	KQU23-M5
	R1/8	-01S	-01S
	R1/4	-02S	-02S
4	M5 X 0.8	KQ2U04-M5	KQU04-M5
	M6 X 1	-M6	-M6
	R1/8	-01S	-01S
	R1/4	-02S	-02S
6	M5 X 0.8	KQ2U06-M5	KQU06-M5
	M6 X 1	-M6	-M6
	R1/8	-01S	-01S
	R1/4	-02S	-02S
8	R1/8	KQ2U08-01S	KQU08-01S
	R1/4	-02S	-02S
	R3/8	-03S	-03S
10	R1/4	KQ2U10-02S	KQU10-02S
	R3/8	-03S	-03S
	R1/2	-04S	-04S
	R1/4	KQ2U12-02S	KQU12-02S
12	R3/8	-03S	-03S
	R1/2	-04S	-04S
	R3/8	KQ2U16-03S	KQU16-03S
16	R1/2	-04S	-04S

<M5, M6>

<R>

Double Universal Male Elbow

KQ2VD/KQVD

To branch the line from the female thread at right angles. 2 individual parts rotate freely.

Applicable tubing O.D. mm	Connecting thread	Model	
		KQ2VD (White)	KQVD (Black)
4	R1/8	KQ2VD04-01S	KQVD04-01S
	R1/4	-02S	-02S
	R3/8	-03S	-03S
	R1/8	KQ2VD06-01S	KQVD06-01S
6	R1/4	-02S	-02S
	R3/8	-03S	-03S
	R1/8	KQ2VD08-01S	KQVD08-01S
8	R1/4	-02S	-02S
	R3/8	-03S	-03S
	R1/2	-04S	-04S
10	R1/4	KQ2VD10-02S	KQVD10-02S
	R3/8	-03S	-03S
	R1/2	-04S	-04S
12	R1/4	KQ2VD12-02S	KQVD12-02S
	R3/8	-03S	-03S
	R1/2	-04S	-04S

Triple Universal Male Elbow

KQ2VT/KQVT

To branch line from the female thread into 3 directions at right angles. 3 individual parts rotate freely.

Applicable tubing O.D. mm	Connecting thread	Model	
		KQ2VT (White)	KQVT (Black)
4	R1/8	KQ2VT04-01S	KQVT04-01S
	R1/4	-02S	-02S
	R3/8	-03S	-03S
6	R1/8	KQ2VT06-01S	KQVT06-01S
	R1/4	-02S	-02S
	R3/8	-03S	-03S
8	R1/8	KQ2VT08-01S	KQVT08-01S
	R1/4	-02S	-02S
	R3/8	-03S	-03S
10	R1/2	-04S	-04S
	R1/4	KQ2VT10-02S	KQVT10-02S
	R3/8	-03S	-03S
12	R1/2	-04S	-04S
	R1/4	KQ2VT12-02S	KQVT12-02S
	R3/8	-03S	-03S
16	R1/2	-04S	-04S